

## PD-130 DTH Integral Drilling and Splitter's Wears Parts list

1、尼龙滑板 ANZP130.01-08/09/10 (Nylon skateboard) 1 套共计  
30 个；



2、钻杆 76-1500 (drill pipe) 1 根



3、 钻头 4 inches-130 (drill bit) 1 件



4、 冲击器 4 inches (impactor) 1 件



5、 回转动力头输出轴 (Output shaft of the rotary power head) 1  
件



6、 前端扶钎器耐磨套 AWZP.09-01  
(Front-end drill holder wear-resistant sleeve) 1 件



7、杆套 AWZP.09-02 (rod sleeve)



8、推进器齿轮 ANZP420C.02.02-07/08 (花键轴和从动轮)

Propeller gear (Splined shaft and driven wheel) 1 套



9、推进马达 BM5-245 (Propulsion motor) 1 件




10、推进器轴承 6206/6207/6010 (Thruster bearing) 1 套, 四个



11、从动轮轴承 6209 (Driven wheel bearing) 1 套两个



12、电磁阀插头 (Solenoid valve plug) 1 件



13、动力头密封 (Power head seal) 1 套



14、顶头截齿 ANZP520B.02.04-09 (top cutting pick) 1 件



15、遥控器电池 RLB-EL7C (Remote control battery) 1 件



16、遥控器充电器 LBC-EL7H (Remote control charger) 1 套



17、劈裂机回转耐磨套 NAWZP.01.04-03

Splitting machine slewing wear-resistant sleeve 1 件



18、劈裂机密封 (Splitter seal) 1 套



19、劈裂机弹簧 ANZP130.01.02-06 (Splitting machine spring) 1 件



20、劈裂机劈块 ANZP130.01.02-07 (Splitter splitting block) 1 套



21、劈裂机楔器 ANZP130.01.02-08 (Splitting machine wedge)

